



71. System: Enable ClearType for Smooth Fonts*

ClearType is a font display technology that smoothes out fonts to improve readability. By default it is disabled in Pocket PC 2002. Here's how to enable it:

1. Today Screen
2. Open "Start Menu"
3. Select "Settings"
4. Open the "System" tab
5. Tap the "Screen" icon
6. Check the "Enable ClearType" box
7. Click "Ok"
8. Soft-reset your Pocket PC